



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015880	Screw	21.	530036575	Foam-Air Filter	44.	530071785	Kit-piston/rod (Incl. 10,45)
2.	530058982	Bolt-Muffler	22.	530057545	Cover-Air Box	45.	530069945	Kit-Conn. Rod
3.	530059825	Assy-Muffler/Shield (Incl. 2)	23.	530035505	Ignition Module	46.	530071750	O-Ring-C'case (kit)
4.	530015953	Screw-Cylinder	24.	530059758	Spacer-Flywheel	47.	530057954	Assy-Plug (incl.46)
5.	952030249	Spark Plug (RCJ 6Y)	25.	530016357	Screw	48.	530016386	Screw
6.	530012541	Cylinder	26.	545015601	Assy-Switch wire	49.	530057539	Shroud-Rear
7.	530071750	Seal-Cylinder (kit)	27.	530016386	Screw	50.	530016445	Retainer-Tank
8.	530055120	Piston Ring	28.	530054834	Handle-Starter	51.	530057974	Assy-Fuel Tank (incl. filter, lines & fuel cap)
9.	530015162	Retainer-Piston Pin	29.	545050409	Kit - Rope	52.	530057973	Assy-Fuel Cap
10.	530071833	Kit - Piston (Incl. 8, 9)	30.	530055122	Assy-Clutch	53.	530069247	Kit-Fuel Line (Small)
11.	530012579	Assy-Crankshaft	31.	530094189	Washer-Clutch	54.	530069216	Kit-Fuel Line (Large)
12.	530012582	Assy-Crankcase (Incl. 41,42,43)	32.	545016004	Assy.-Fan Hsg	55.	530095646	Assy-Fuel Pickup
13.	530071750	Seal-Cyl/Carb.(kit)	33.	545054901	Spring-Starter	56.	530071750	Kit-Engine Gasket (Incl. 7,13,16,46)
14.	530057547	Adapter-Carb.	34.	545050407	Kit-Starter Pulley	57.	530150247	Assy-Clutch Drum
15.	530016441	Screw	35.	545080601	Baffle	58.	545077301	Assy-Clutch Cover (Incl. 61,62)
16.	530071750	Gasket-Carb. (kit)	36.	530015880	Screw	59.	530016319	Screw-Align
17.	530071811	Kit-Carb.(C1U-W19)	37.	530016463	Washer-Clutch Flat	60.	530015772	Screw
(Note: Repair kits are not available for this carburetor)			38.	530039243	Assy-Flywheel	61.	530016381	Screw 12-24
18.	530058709	Bulb-Purge	39.	545102101	Assy-C'case & C'shaft (Incl. 11,12,40)	62.	530016382	Nut 12-24
19.	530059246	Air Box	40.	530015941	Retain. Ring-C'shaft	63.	530015814	Screw
20.	530016429	Screw	41.	530055728	Outer Bearing			
			42.	530019264	Seal-C'shaft			
			43.	530032125	Inner Bearing			

✓ = NEW PART NUMBER FOR THIS IPL * = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)