





Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015957	Screw	26.	530010845	Assy-Fuel Cap	49.	530016080	Screw
2.	530071272	Cover-Handle (kit)	27.	530037514	Assy-Chassis (Incl. 22,23,24,26,42,46)	50.	530042095	Spring-Recoil
3.	530036097	Trigger-Throttle				51.	545008803	Housing-Fan
4.	530036098	Lockout-Throttle				52.	530015892	Screw
5.	530053443	Lever-Choke	28.	530069572	Kit-Switch	53.	530015814	Screw
6.	530015937	Screw	29.	530029833	Worm-Oil Pump	54.	530015158	Washer
7.	530038985	Spring-Isolator	30.	530014410	Assy.-Oil Pump	55.	530038327	Handle-Front
8.	530071272	Handle-Rear (kit)	31.	530015896	Screw	56.	530036113	Front Strap-AV
9.	530015906	Screw	32.	530069342	Kit-Clutch Drum (Incl. #35)	57.	530015775	Screw-Plate
10.	530038986	Spring-Isolator	33.	530015611	Washer-Clutch	58.	530036101	Plate-Isolator
11.	530038471	Assy-Throttle Cable (Incl. Grommet)	34.	530014949	Assy-Clutch	59.	530038985	Spring-Isolator
12.	530069232	Kit-Rope	35.	530032119	Bearing-Clutch	60.	530015984	Screw
13.	530056422	Handle-Starter	36.	530015907	Washer-Thrust	61.	530051317	Chain"- 20"
14.	530071966	Kit-Starter EPS (Incl. 15,16,17,49)	37.	545047801	Pickup-Oil	62.	530044695	Bar -20"
15.	530021180	Spring EPS	38.	530056533	Filter-Oil	63.	530016064	Screw
16.	530059677	Hub-Starter EPS	39.	530016037	Screw	64.	545051201	Cover-Gear
17.	530021179	Screw-Shoulder	40.	530015814	Screw	65.	545185201	Pin-Bar Adjust
18.	530047667	Plate-Baffle Fan	41.	530029850	Chain Catcher	66.	545149301	Clip-Spring
19.	530016134	Nut-Flywheel	42.	530015877	Bar Bolt	67.	545060401	Screw-Adjuster
20.	530015127	Washer-Flywheel	43.	530047855	Bar Plate	68.	545060201	Gear-Idler
21.	530059637	Assy-Flywheel	44.	530016439	Screw	69.	525884202	Assy-Gear Adj. wheel
22.	530036043	Plate-Support (Bar Stud)	45.	530014381	Kit-Spike Assy(incl#44)	70.	545097303	Assy-ChainBrake
23.	530029868	Plug-Vent	46.	530057236	Assy-Oil Cap	71. ✓	579107103	Assy - EZT Knob
24.	530026119	Valve-Check	47.	530055406	Shield-Heat			
25.	530015922	Nut-Speed	48.	530055322	Clip-"U"			

✓ = NEW PART NUMBER FOR THIS IPL

\* = REFER TO THE SERVICE REFERENCE INDICATED FOR MORE INFORMATION. (LOCATED AT END OF IPL)